

# Low Fluorescence Western Membrane (PVDF) ab133411

★★★★★ [1 Abreviews](#) [7 References](#)

### 製品の概要

製品名	Low Fluorescence Western Membrane (PVDF)
アプリケーション	適用あり: WB
特記事項	Pre-cut membranes (10 sheets, 7 x 9 cm), compatible with gels 10 x 10 cm and smaller. Note: PVDF membranes must be activated prior to use. Membrane activation protocol: 1. Pre-wet the membrane in methanol for a few moments until the membrane is completely wet. 2. Transfer the wet membrane from methanol to purified water and incubate on a rocker or shaker for at least 5 minutes. Make sure that the membrane is fully immersed in water and does not float on the water's surface. 3. Transfer the membrane from water to transfer buffer, and incubate for 5 minutes.

### 製品の特性

製品の状態	Solid
保存方法	Store at room temperature.

### アプリケーション

**The Abpromise guarantee**      **Abpromise保証は、次のテスト済みアプリケーションにおけるab133411の使用に適用されます**  
アプリケーションノートには、推奨の開始希釈率がありますが、適切な希釈率につきましてはご検討ください。

アプリケーション	Abreviews	特記事項
WB		Use at an assay dependent concentration.

**Please note:** All products are "FOR RESEARCH USE ONLY. NOT FOR USE IN DIAGNOSTIC PROCEDURES"

### Our Abpromise to you: Quality guaranteed and expert technical support

- Replacement or refund for products not performing as stated on the datasheet
- Valid for 12 months from date of delivery

- Response to your inquiry within 24 hours
- We provide support in Chinese, English, French, German, Japanese and Spanish
- Extensive multi-media technical resources to help you
- We investigate all quality concerns to ensure our products perform to the highest standards

If the product does not perform as described on this datasheet, we will offer a refund or replacement. For full details of the Abpromise, please visit <https://www.abcam.co.jp/abpromise> or contact our technical team.

### **Terms and conditions**

---

- Guarantee only valid for products bought direct from Abcam or one of our authorized distributors