

# ab125966 – FGF-21 Human ELISA Kit

Inetri	ictions	for	مءا ا
111121111	ICHOHS	1()1	>-

For the quantitative measurement of Human FGF-21 in plasma, serum, and cell culture supernatants.

This product is for research use only and is not intended for diagnostic use.

# **Table of Contents**

INTI	RODUCTION	
1.	BACKGROUND	2
2.	ASSAY SUMMARY	3
GEN	NERAL INFORMATION	
3.	PRECAUTIONS	4
4.	STORAGE AND STABILITY	4
5.	MATERIALS SUPPLIED	4
6.	MATERIALS REQUIRED, NOT SUPPLIED	5
7.	LIMITATIONS	5
8.	TECHNICAL HINTS	6
ASS	SAY PREPARATION	
9.	REAGENT PREPARATION	7
10.	STANDARD PREPARATIONS	10
11.	SAMPLE PREPARATION	13
12.	PLATE PREPARATION	13
ASS	SAY PROCEDURE	
13.	ASSAY PROCEDURE	14
DAT	TA ANALYSIS	
14.	CALCULATIONS	16
15.	TYPICAL DATA	17
16.	TYPICAL SAMPLE VALUES	18
17.	ASSAY SPECIFICITY	19
RES	SOURCES	
18.	TROUBLESHOOTING	20
19.	NOTES	22

#### INTRODUCTION

#### 1. BACKGROUND

Abcam's FGF-21 Human in vitro ELISA (Enzyme-Linked Immunosorbent Assay) kit is designed for the quantitative measurement of Human FGF-21 in plasma, serum, and cell culture supernatants.

A FGF-21 specific antibody has been precoated onto 96-well plates and blocked. Standards or test samples are added to the wells and subsequently a FGF-21 specific biotinylated detection antibody is added and then followed by washing with wash buffer. Streptavidin-Peroxidase Conjugate is added and unbound conjugates are washed away with wash buffer. TMB is then used to visualize Streptavidin-Peroxidase enzymatic reaction. TMB is catalyzed by Streptavidin-Peroxidase to produce a blue color product that changes into yellow after adding acidic stop solution. The density of yellow coloration is directly proportional to the amount of FGF-21 captured in plate.

Fibroblast growth factor 21 (FGF-21) is a member of endocrine FGF subfamily, along with FGF-19 and FGF-23. The secreted Human FGF-21 is expressed in liver, pancreas, and white adipose tissue. It contains 209 amino acids in the precursor and 181 amino acids in the mature protein with a molecular mass of about 20 kDa, and has 75% homology with mouse FGF-21. FGF-21 signals through cell-surface tyrosine kinase FGF receptors complexed with a cofactor  $\beta$ -Klotho. FGF-21 is a novel metabolic regulator involved in glucose metabolism, lipolysis, and ketogenesis and triglyceride clearance, growth hormone signaling, and metabolic diseases. In rodent models of diabetes, it stimulates glucose uptake in adipocytes, protects animals from dietinduced obesity, and lowers blood glucose and triglyceride.

#### INTRODUCTION

#### 2. ASSAY SUMMARY

#### Primary capture antibody



Prepare all reagents, samples and standards as instructed.

#### Sample



Add standard or sample to each well used. Incubate at room temperature.

#### Primary detector antibody



Wash and add prepared biotin antibody to each well. Incubate at room temperature.

#### Streptavidin Label



Wash and add prepared Streptavidin-Peroxidase Conjugate. Incubate at room temperature.

#### Substrate Colored product



Add Chromogen Substrate to each well. Incubate at room temperature. Add Stop Solution to each well. Read immediately.

#### **GENERAL INFORMATION**

#### 3. PRECAUTIONS

Please read these instructions carefully prior to beginning the assay.

Modifications to the kit components or procedures may result in loss of performance.

#### 4. STORAGE AND STABILITY

Store kit at 4°C immediately upon receipt, apart from the SP Conjugate & Biotinylated Antibody, which should be stored at -20°C.

Refer to list of materials supplied for storage conditions of individual components. Observe the storage conditions for individual prepared components in sections 9 & 10.

#### 5. MATERIALS SUPPLIED

Item	Amount	Storage Condition (Before Preparation)
FGF-21 Microplate (12 x 8 well strips)	96 wells	4°C
FGF-21 Standard	1 vial	4°C
10X Diluent N Concentrate	30 mL	4°C
Biotinylated Human FGF-21 Antibody	1 vial	-20°C
100X Streptavidin-Peroxidase Conjugate (SP Conjugate)	80 µL	-20°C
Chromogen Substrate	7 mL	4°C
Stop Solution	11 mL	4°C
20X Wash Buffer Concentrate	2 x 30 mL	4°C
Sealing Tapes	3	N/A
Standard Diluent	1 vial	4°C

#### **GENERAL INFORMATION**

#### 6. MATERIALS REQUIRED, NOT SUPPLIED

These materials are not included in the kit, but will be required to successfully utilize this assay:

- 1 Microplate reader capable of measuring absorbance at 450 nm.
- Precision pipettes to deliver 1 µL to 1 mL volumes.
- Adjustable 1-25 mL pipettes for reagent preparation.
- 100 mL and 1 liter graduated cylinders.
- Absorbent paper.
- Distilled or deionized water.
- Log-log graph paper or computer and software for ELISA data analysis.
- 8 tubes to prepare standard or sample dilutions.

#### 7. LIMITATIONS

 Do not mix or substitute reagents or materials from other kit lots or vendors.

#### **GENERAL INFORMATION**

#### 8. TECHNICAL HINTS

- Samples generating values higher than the highest standard should be further diluted in the appropriate sample dilution buffers.
- Avoid foaming or bubbles when mixing or reconstituting components.
- Avoid cross contamination of samples or reagents by changing tips between sample, standard and reagent additions.
- Ensure plates are properly sealed or covered during incubation steps.
- Complete removal of all solutions and buffers during wash steps.
- This kit is sold based on number of tests. A 'test' simply refers to a single assay well. The number of wells that contain sample, control or standard will vary by product. Review the protocol completely to confirm this kit meets your requirements. Please contact our Technical Support staff with any questions.

#### 9. REAGENT PREPARATION

Equilibrate all reagents to room temperature (18-25°C) prior to use. Prepare fresh reagents immediately prior to use. If crystals have formed in the concentrate, make sure to rinse the bottles thoroughly to extract any precipitate left in the bottle, then mix gently until the crystals have completely dissolved.

#### 9.1 1X Diluent N

Dilute the 10X Diluent N Concentrate 1:10 with reagent grade water. Mix gently and thoroughly. Store for up to 1 month at 4°C.

#### 9.2 1X Wash Buffer

Dilute the 20X Wash Buffer Concentrate 1:20 with reagent grade water. Mix gently and thoroughly.

#### 9.3 1X Biotinylated FGF-21 Detector Antibody

- 9.3.1 The stock Biotinylated FGF-21 Antibody must be diluted with 1X Diluent N according to the label concentration to prepare 1X Biotinylated FGF-21 Antibody for use in the assay procedure. Observe the label for the "X" concentration on the vial of Biotinylated FGF-21 Antibody.
- 9.3.2 Calculate the necessary amount of 1X Diluent N to dilute the Biotinylated FGF-21 Antibody to prepare a 1X Biotinylated FGF-21 Antibody solution for use in the assay procedure according to how many wells you wish to use and the following calculation:

Number of Wells Strips	Number of Wells	(V <sub>T</sub> ) Total Volume of 1X Biotinylated Detector Antibody (μL)
4	32	1,760
6	48	2,640
8	64	3,520
10	80	4,400
12	96	5,280

Any remaining solution should be frozen at -20°C.

#### Where:

- C<sub>S</sub> = Starting concentration (X) of stock Biotinylated FGF-21 Antibody (variable)
- C<sub>F</sub> = Final concentration (always = 1X) of 1X Biotinylated FGF-21 Antibody solution for the assay procedure
- $V_T$  = Total required volume of 1X Biotinylated FGF-21 Antibody solution for the assay procedure
- $V_A$  = Total volume of (X) stock Biotinylated FGF-21 Antibody
- V<sub>D</sub> = Total volume of 1X Diluent N required to dilute (X) stock Biotinylated FGF-21 Antibody to prepare 1X Biotinylated Antibody solution for assay procedures

Calculate the volume of (X) stock Biotinylated Antibody required for the given number of desired wells:

$$(C_F / C_S) \times V_T = V_A$$

<u>Calculate the final volume of 1X Diluent N required to prepare the 1X Biotinylated FGF-21 Antibody:</u>

$$V_T - V_A = V_D$$

#### Example:

NOTE: This example is for demonstration purposes only. Please remember to check your antibody vial for the actual concentration of antibody provided.

- C<sub>S</sub> = 50X Biotinylated FGF-21 Antibody stock
- $C_F$  = 1X Biotinylated FGF-21 Antibody solution for use in the assay procedure
- $V_T$  = 3,520  $\mu$ L (8 well strips or 64 wells)

$$(1X/50X) \times 3,520 \ \mu L = 70.4 \ \mu L$$

$$3,520~\mu L$$
 -  $70.4~\mu L$  =  $3,449.6~\mu L$ 

- $V_A$  = 70.4  $\mu$ L total volume of (X) stock Biotinylated FGF-21 Antibody required
- V<sub>D</sub> = 3,449.6 μL total volume of 1X Diluent N required to dilute the 50X stock Biotinylated Antibody to prepare 1X Biotinylated FGF-21 Antibody solution for assay procedures

- 9.3.3 First spin the Biotinylated FGF-21 Antibody vial to collect the contents at the bottom.
- 9.3.4 Add calculated amount  $V_A$  of stock Biotinylated FGF-21 Antibody to the calculated amount  $V_D$  of 1X Diluent N. Mix gently and thoroughly.

#### 9.4 1X SP Conjugate

Spin down the 100X Streptavidin-Peroxidase Conjugate (SP Conjugate) briefly and dilute the desired amount of the conjugate 1:100 with 1X Diluent N.

Any remaining solution should be frozen at -20°C.

#### 9.5 Standard Diluent

Spin down the Standard diluent before opening

#### 10. STANDARD PREPARATIONS

- Prepare serially diluted standards immediately prior to use.
  Always prepare a fresh set of standards for every use.
- Any remaining standard should be stored at -20°C after reconstitution and used within 5 days.
- This procedure prepares sufficient standard dilutions for duplicate wells.
  - 10.1 Reconstitution of the FGF-21 Standard vial to prepare a 10 ng/mL FGF-21 **Stock Standard**.
    - 10.1.1 First consult the FGF-21 Standard vial to determine the mass of protein in the vial.
    - 10.1.2 Calculate the appropriate volume of Standard Diluent to add when resuspending the FGF-21 Standard vial to produce a 10 ng/mL FGF-21 Stock Standard by using the following equation:

C<sub>S</sub> = Starting mass of FGF-21 Standard (see vial label) (ng)

C<sub>F</sub> = The 10 ng/mL FGF-21 **Stock Standard** final required concentration

V<sub>D</sub> = Required volume of Standard Diluent for reconstitution (μL)

<u>Calculate total required volume Standard Diluent for</u> resuspension:

$$(C_S / C_F) \times 1,000 = V_D$$

#### Example:

NOTE: This example is for demonstration purposes only. Please remember to check your standard vial for the actual amount of standard provided.

 $C_S$  = 2 ng of FGF-21 Standard in vial

C<sub>F</sub> = 10 ng/mL FGF-21 **Stock Standard** final concentration

 $V_D$  = Required volume of Standard Diluent for reconstitution

 $(2 \text{ ng} / 10 \text{ ng/mL}) \times 1,000 = 200 \mu L$ 

- 10.1.3 First briefly spin the FGF-21 Standard Vial to collect the contents on the bottom of the tube.
- 10.1.4 Reconstitute the FGF-21 Standard vial by adding the appropriate calculated amount  $V_D$  of Standard Diluent to the vial to generate the 10 ng/mL FGF-21 **Stock Standard**. Mix gently and thoroughly.
  - 10.1.5 Allow the reconstituted 10 ng/mL FGF-21 Standard to sit for 10 minutes with gentle agitation prior to making subsequent dilutions
- 10.1.6 Prepare **Standard #1** by diluting the stock standard 5-fold with 1x Diluent N.
- 10.2 Label seven tubes #2-8.
- 10.3 Add 120  $\mu$ L of 1X Diluent N to tubes #2 8.
- 10.4 To prepare **Standard #2**, add 120 μL of the **Standard #1** into tube #2 and mix gently.
- 10.5 To prepare **Standard #3**, add 120 μL of the **Standard #2** into tube #3 and mix gently.
- 10.6 Using the table below as a guide, prepare subsequent serial dilutions.
- 10.7 1X Diluent N serves as the zero standard, 0 ng/mL (tube #8).

### **Standard Dilution Preparation Table**

Standard #	Volume to Dilute (μL)	Volume Diluent N (µL)	Total Volume (µL)	Starting Conc. (ng/mL)	Final Conc. (ng/mL)
1		Step	10.1.6		2.000
2	120	120	240	2.000	1.000
3	120	120	240	1.000	0.500
4	120	120	240	0.500	0.250
5	120	120	240	0.250	0.125
6	120	120	240	0.125	0.063
7	120	120	240	0.063	0.031
8	-	120	120	-	0



#### 11. SAMPLE PREPARATION

#### 11.1 Plasma

Collect plasma using one-tenth volume of 0.1 M sodium citrate as an anticoagulant. Centrifuge samples at  $3,000 \times g$  for 10 minutes. Dilute samples 1:2 into 1X Diluent N. Optimal dilution should be determined depending on application needs. The undiluted samples can be stored at  $20^{\circ}$ C or below for up to 3 months. Avoid repeated freezethaw cycles. (EDTA or Heparin can also be used as anticoagulant).

#### 11.2 **Serum**

Samples should be collected into a serum separator tube. After clot formation, centrifuge samples at  $3,000 \times g$  for 10 minutes and. remove serum. Dilute samples 1:2 into 1X Diluent N. Optimal dilution should be determined depending on application needs. The undiluted samples can be stored at -20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles.

#### 11.3 Cell Culture Supernatants

Centrifuge cell culture media at 3000 x g for 10 minutes at 4°C to remove debris. Collect supernatants, and if necessary dilute samples into Diluent N; optimal dilution should be determined depending on application needs. Store undiluted samples at -20°C or below. Avoid repeated freeze-thaw cycles.

Final Dilution	Step 1	Step 2	Step 3
100	4 μL Sample + 396 μL Buffer	NA	NA
1000	4 μL Sample + 396 μL Buffer	24 μL Sample(Step 1) + 216 μL Buffer	NA
10,000	4 μL Sample + 396 μL Buffer	4 μL Sample(Step 1)	NA

		+ 396 µL Buffer	
100,000	4 μL Sample + 396 μL Buffer	4 μL Sample(Step 1) + 396 μL Buffer	24 µL Sample(Step 2) + 216 µL Buffer

#### 12. PLATE PREPARATION

- The 96 well plate strips included with this kit are supplied ready to use. It is not necessary to rinse the plate prior to adding reagents.
- Unused well plate strips should be returned to the plate packet and stored at 4°C.
- For statistical reasons, we recommend each sample should be assayed with a minimum of two replicates (duplicates).
- Well effects have not been observed with this assay. Contents of each well can be recorded on the template sheet included in the Resources section.

#### **ASSAY PROCEDURE**

#### 13. ASSAY PROCEDURE

- Equilibrate all materials and prepared reagents to room temperature (18 25°C) prior to use.
- It is recommended to assay all standards, controls and samples in duplicate.
  - 13.1 Prepare all reagents, working standards and samples as instructed. Equilibrate reagents to room temperature before use. The assay is performed at room temperature (18-25°C).
  - 13.2 Remove excess microplate strips from the plate frame and return them immediately to the foil pouch with desiccant inside. Reseal the pouch securely to minimize exposure to water vapor and store in a vacuum desiccator.
  - 13.3 Add 50 µL of FGF-21 Standard or sample to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for two hours. Start the timer after the last sample addition.
  - 13.4 Wash five times with 200 μL of 1X Wash Buffer manually. Invert the plate each time and decant the contents; tap it 4-5 times on absorbent paper towel to completely remove the liquid. If using a machine wash six times with 300 μL of 1X Wash Buffer and then invert the plate, decant the contents; tap it 4-5 times on absorbent paper towel to completely remove the liquid.
  - 13.5 Add 50  $\mu$ L of 1X Biotinylated FGF-21 Antibody to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with sealing tape and incubate for one hour.
  - 13.6 Wash microplate as described above.
  - 13.7 Add 50 µL of 1X SP Conjugate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with sealing tape and

#### **ASSAY PROCEDURE**

- incubate for 30 minutes. Turn on the microplate reader and set up the program in advance.
- 13.8 Wash microplate as described above.
- 13.9 Add 50 μL of Chromogen Substrate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed and incubate in ambient light for 30 minutes or until the optimal blue colour density develops.
- 13.10 Add 50 µL of Stop Solution to each well. The color will change from blue to yellow. Gently tap plate to ensure thorough mixing. Break any bubbles that may have formed.
- 13.11 Read the absorbance on a microplate reader at a wavelength of 450 nm immediately. If wavelength correction is available, subtract readings at 570 nm from those at 450 nm to correct optical imperfections. Otherwise, read the plate at 450 nm only. Please note that some unstable black particles may be generated at high concentration points after stopping the reaction for about 10 minutes, which will reduce the readings.


### 14. CALCULATIONS

Calculate the mean value of the triplicate readings for each standard and sample. To generate a Standard Curve, plot the graph using the standard concentrations on the x-axis and the corresponding mean 450 nm absorbance on the y-axis. The best-fit line can be determined by regression analysis using log-log or four-parameter logistic curve-fit. Determine the unknown sample concentration from the Standard Curve and multiply the value by the dilution factor.

### 15. TYPICAL DATA

**TYPICAL STANDARD CURVE** – Data provided for demonstration purposes only. A new standard curve must be generated for each assay performed.

Human FGF-21 Standard Curve



### 16. TYPICAL SAMPLE VALUES

#### SENSITIVITY -

The minimum detectable dose of FGF-21 is typically 20 pg/mL.

#### **RECOVERY -**

Standard Added Value: 0.063 - 0.5 ng/mL

Recovery %: 92 – 115. Average Recovery %: 101

#### **LINEARITY OF DILUTION -**

Plasma Dilution	Average % Expected Value
No dilution	85
1:2	98
1:4	117

Serum Dilution	Average % Expected Value
No dilution	100
1:2	98
1:4	102

#### PRECISION -

	Intra- Assay	Inter- Assay
% CV	5.2	9.7

### 17. ASSAY SPECIFICITY

Species	% Cross Reactivity
Canine	70
Mouse	30
Monkey	100
Bovine	70
Rat	60
Swine	70
Rabbit	None

 No significant cross-reactivity observed with FGF-2, FGF-12, and FGF-17.

### 18. TROUBLESHOOTING

Problem	Cause	Solution
Poor standard curve	Improper standard dilution	Confirm dilutions made correctly
	Standard improperly reconstituted (if applicable)	Briefly spin vial before opening; thoroughly resuspend powder (if applicable)
	Standard degraded	Store sample as recommended
	Curve doesn't fit scale	Try plotting using different scale
	Incubation time too short	Try overnight incubation at 4°C
	Target present below	Decrease dilution factor;
	detection limits of assay	concentrate samples
Low signal	Precipitate can form in wells upon substrate addition when concentration of target is too high	Increase dilution factor of sample
	Using incompatible sample type (e.g. serum vs. cell extract)	Detection may be reduced or absent in untested sample types
	Sample prepared incorrectly	Ensure proper sample preparation/dilution
	Bubbles in wells	Ensure no bubbles present prior to reading plate
Large CV	All wells not washed equally/thoroughly	Check that all ports of plate washer are unobstructed wash wells as recommended
	Incomplete reagent mixing	Ensure all reagents/master mixes are mixed thoroughly
	Inconsistent pipetting	Use calibrated pipettes and ensure accurate pipetting
	Inconsistent sample preparation or storage	Ensure consistent sample preparation and optimal sample storage conditions (eg. minimize freeze/thaws cycles)

Problem	Cause	Solution
High background/ Low sensitivity	Wells are insufficiently washed	Wash wells as per protocol recommendations
	Contaminated wash buffer	Make fresh wash buffer
	Waiting too long to read plate after adding STOP solution	Read plate immediately after adding STOP solution
	Improper storage of ELISA kit	Store all reagents as recommended. Please note all reagents may not have identical storage requirements.
	Using incompatible sample type (e.g. Serum vs. cell extract)	Detection may be reduced or absent in untested sample types

# 19. <u>NOTE</u>



#### For all technical and commercial enquires please go to:

www.abcam.com/contactus www.abcam.cn/contactus (China) www.abcam.co.jp/contactus (Japan)

Copyright © 2022 Abcam, All Rights Reserved. The Abcam logo is a registered trademark. All information / detail is correct at time of going to print.